

PMCS/Maintenance

FILTER POINTS (engine, transmission, hydraulics, emergency steering, transfer case)	PLS	HEMTT	HET	*HEMTT+
SERVICED RESERVOIRS	5	4	4	1
LUBRICANT FILTER POINTS (REPLACEABLE ELEMENT)	4	3	3	3
SERVICE FLUIDS	2	3	2	1
LUBRICATION CHECK POINTS	5	4	4	1
LUBRICANT FILL POINTS	5	4	4	1
UNFILTERED PMCS LUBRICANT FILL POINTS	5	4	4	0

Axle lubrication, not shown

*HEMTT+ w/ engine sump top-off option

